

# F-COM



CE EN 54-2  
EN 54-4  
EN 54-21



# F-COM

Telephone communicator

---

Programming manual

---

**inim**

## License Agreement (EULA)

This license agreement (EULA) is a legal agreement between the User (be it an individual or a single entity) and the author of this software (Inim Electronics S.r.l.).

By installing, copying or using the software product in any way, this agreement is implicitly and fully accepted. If you do not agree to the terms of this agreement, do not install or use the software product.

All versions of this software are protected by copyright laws and international agreements on copyright and intellectual property rights. Inim Electronics S.r.l. holds all rights. The software cannot be duplicated, sold, distributed or used in any way not described in this document without the written permission of Inim Electronics S.r.l..

Parties interested in using the software for non-personal use should contact Inim Electronics S.r.l..

### Privileges granted

This license grants the following rights: installation and use. The installation and use an unlimited number of copies of this product.

### Reproduction and distribution

Reproduction and distribution in an unlimited number of copies of this software is granted; each copy must contain all the parts of the software and be accompanied by a copy of this EULA.

The software cannot be included in any other freeware, shareware or commercial package or product without the explicit consent of the Inim Electronics S.r.l..

### Description of other rights and limitations

Reverse engineering, decompilation, disassembly and any type of alteration of the product is prohibited.

### Separation of the components

The software is licensed as a single product; none of its parts can be separated and used on more than one computer.

### Transfer of software

Permanent transfer of the software to third parties is allowed, within the scope of what is specified in this EULA.

### Termination

License rights automatically expire if the User does not comply with the terms of this EULA. In such a case, you must destroy all copies of the software and its components.

By using this software, you accept the terms of this license.

### Copyright

With the exception of what may be explicitly noted, all rights and copyrights on the software and its parts (including images, photographs, animations, video, audio, music, texts and code) and on any accompanying documents are owned by Inim Electronics S.r.l..

This software is protected by copyright laws and international agreements and must be considered in the same way as any material subject to copyright.

### Warranty limitations

Inim Electronics S.r.l. expressly excludes any warranty regarding this product. The software and all the attached material is released as is, without warranties of any kind, explicit or implicit. All risks deriving from the functioning or from the non-functioning of the software are the responsibility of the User.

### Limitation of liability

In no case may the author of this software be held liable for any direct or indirect damage of any kind (including, without limitation, for loss of profits, interruption of services or loss of data) resulting from the use or from the impossibility of using the product.



## Table of contents

<b>1. The F-COM communicator</b>	<b>6</b>
1.1 Manufacturer's details	6
1.2 Device description	6
1.3 Access levels	7
1.4 Manuals	7
1.4.1 Manual details	8
<b>2. The F-COM/STUDIO software</b>	<b>9</b>
2.1 Description of the software	9
2.2 Initial page	9
2.3 Application functions	10
2.4 Connection of the software to the communicator	11
2.5 Installing the software	12
2.5.1 Software requirements	12
2.5.2 Installation procedure	12
2.6 Events log	12
2.7 Real-time	13
<b>3. Programming via software</b>	<b>14</b>
3.1 Programming	14
3.2 Settings	14
3.2.1 Pay-as-you-go balance	16
3.3 Input/Output terminals	17
3.4 Phonebook (Contacts)	19
3.5 Events	21
3.6 Events/Actions	23
3.6.1 Events enabled by default	26
3.6.2 Events/Actions default parameters	27
3.7 SMS text message library	29
3.8 Voice message library	29



# 1. The F-COM communicator

## 1.1 Manufacturer's details

Manufacturer: Inim Electronics S.r.l.  
Production plant: Centobuchi, via Dei Lavoratori 10  
63076 Montepandone (AP)  
Tel.: +39 0735 705007  
Fax: +39 0735 70491  
e-mail: info@inim.it  
Web: www.inim.it

The persons authorized by the manufacturer to repair or replace the parts of this system have authorization to work only on devices marketed under the brand name Inim Electronics.

## 1.2 Device description

The F-COM is a universal autonomous telephone communicator, certified in accordance with EN 54-21 and EN 54-4 standards. It is to be used with fire detection control panels manufactured both by Inim Electronics and other manufacturers.

It is capable of operating as:

- fire alarm transmission device (device E for EN 54-1)
- fault signal transmission device (device J for EN 54-1)

The communicator operates autonomously:

- It detects control panel alarm and fault events through input terminals, as well as its own internal events.
- Activates programmable outputs.
- Makes voice calls over the PSTN line or GSM mobile network.
- The default voice messages can be replaced by recorded custom messages.
- Sends digital messages using Contact ID protocol (over the PSTN line or GSM mobile network) and SIA-IP (over mobile data network).
- Sends SMS messages over GSM network.
- The default messages can be replaced by custom text messages.
- Provides communication feedback through the ALARM ACK output terminal and LED signals.

---

### **WARNING!**

**Inim Electronics does not ensure full availability of all the GSM functions described in this manual for the various combinations of GSM service provider, SIM type and telephone set used.**

---

## 1.3 Access levels

The F-COM communicator manages different access levels to the device, distinct from the system usability limitations.

Each user must have an access PIN the first digit of which characterizes the typology and cannot be changed:

**Table 1.1:** Access levels

Description	Access mode	Access mode
<b>Standard user</b>	Access to the viewing of: <ul style="list-style-type: none"> <li>• diagnostic information</li> <li>• fault details</li> <li>• events log user PIN</li> </ul>	User PIN Default 000000
<b>Advanced user</b>	The same permissions as the standard user, plus the possibility to change some programming options relating to the contacts: <ul style="list-style-type: none"> <li>• telephone numbers</li> <li>• communication protocol</li> <li>• IP address, port, account code</li> </ul>	Advanced user PIN Default 111111
<b>Installer</b>	The same permissions as the standard user, plus the possibility to carry out the battery test.  By means of the programming software, change all the programming options.	Installer PIN Default 222222

## 1.4 Manuals

Manuals which are not supplied with the apparatus can be ordered directly, by indicating their respective codes in the order, or downloaded from [www.inim.it](http://www.inim.it).

### Installation and User manual

The installation manual contains the technical specifications of all the system components and the instructions for their installation, including instructions and wiring diagrams relating to the various modules.

It also contains the instructions for system commissioning

In order to provide adequate protection, the installer must adhere to all the manufacturer's guidelines relating to the active and passive security devices of this system.

This manual contains instructions relating to the user interface of the F-COM communicator, its functions and use.

### Programming manual (this manual)

The Programming manual contains instructions for the configuration and programming of the F-COM communicator, as well as the descriptions of all the parameters and options.

It also contains the F-COM/STUDIO software instructions, its description, method of installation and use.

It is the responsibility of the person who programs the F-COM communicator to adhere to the instructions and to have complete knowledge of the software in order to work swiftly and properly through the configuration and programming procedures.

### **1.4.1 Manual details**

**Manual code**

DCMPINE0FCOM

**Revision**

1.10

## 2. The F-COM/STUDIO software

### 2.1 Description of the software

F-COM/STUDIO is the software for programming and managing the F-COM telephone communicator manufactured by Inim Electronics.

The software connects with the communicator via the USB port of the PC in use.

#### Commands

The operator interacts with the system in real time: it is possible to check the communications in progress, the status of inputs and outputs, any faults present, diagnostic information relating to the GSM network and the power supply module.

#### Solutions

The set of programming parameters constitute a solution.

A solution is dedicated to a device and its installation.

A solution can be created or changed even without being connected to the apparatus. For example, you can plan the layout of an installation or set the options/parameters at your office and write and test the settings on the apparatus at a later time.

#### Database

F-COM/STUDIO allows you to create and manage a database containing the programming data, maintenance details and events history of all the created installations.

Each new solution can be saved for future maintenance purposes and/or used as a "model" for other installations. The F-COM/STUDIO software uses its own archive/database.

**Table 2.2:** *Minimum requirements and technical characteristics*

<b>Hardware</b>	<ul style="list-style-type: none"> <li>• Pentium 4 Processors (3.2 GHz)</li> <li>• 2 GB Ram</li> <li>• Voice board</li> </ul>
<b>Operative system</b>	<ul style="list-style-type: none"> <li>• Windows Vista, Vista 64</li> <li>• Windows Seven, Seven 64</li> <li>• Windows 8, 8 64</li> <li>• Windows 8.1, 8.1 64</li> <li>• Windows 10, 10 64</li> </ul>
<b>Required hard disk space</b>	500 MB
<b>Minimum video resolution</b>	800 x 600
<b>Connection interface</b>	USB


Microsoft® and Windows® are the registered trademarks of Microsoft Corporation.

### 2.2 Initial page

When the software starts the start page will appear.

The initial page of the F-COM/STUDIO software is divided in three sections:

**Table 2.3:** Home page



[A]	Icon bar for application-related functions ("Application functions" below).
[B]	Programming section icon bar ("Programming" on page 14).
[C]	Main template with parameters and options related to the selected programming section

## 2.3 Application functions

The section at the top of the F-COM/STUDIO software window is common to all the programming sections and the start page.

It shows buttons for access to sections or to software management functions or to open solutions.

**Table 2.4:** Menu bar

Button		Function
	<b>Read</b>	Once the communicator is connected, this function allows the program to load the programming status to the PC with the exception of the parameters of: <ul style="list-style-type: none"> <li>voice messages</li> <li>events log</li> </ul>
	<b>Write</b>	Once the communicator is connected, this function allows the program to load the ongoing programming to the communicator with the exception of the parameters of the voice messages:
	<b>New solution</b>	F-COM/STUDIO software solution management functions.
	<b>Open solution</b>	
	<b>Save solution</b>	
	<b>Installer PIN</b>	Button to open a window for entry of the installer PIN (Access levels).
	<b>Set serial port</b>	Button to open a window for the PC USB port in use for the software to the communicator connection ("Connection of the software to the communicator" below).
	<b>Select language</b>	Button to open a window to indicate the software language.
	<b>Help guide</b>	Button to access this manual.

## 2.4 Connection of the software to the communicator

The connection with the communicator is required during all write and read operations (to/from the communicator).

The connection with the PC can be achieved through a USB cable inserted into the appropriate connector on the main board..

Once the F-COM is connected, the driver for the installation of the USB device recognized by the PC is available in the F-COM/STUDIO software installation folder, specifically in the following folder (in the case of a default installation): C:\Program Files\F-COM/STUDIO\drivers\

The **Set serial port** button allows you to indicate the serial port used by the USB connector.



If it has not already been entered (by means of the appropriate **Installer PIN**) button, at the first attempt to contact the communicator (reading or writing of the programming data) the software will request, once and for all, the PIN necessary for programming (Access levels).



## 2.5 Installing the software

The F-COM/STUDIO software must be installed using the setup.exe file that can be downloaded from the reserved area of the website [www.inim.it](http://www.inim.it).

It is suggested to check this page of the site periodically in order to have information regarding the most recent revision of the software and therefore to be able to make the appropriate updates.

### 2.5.1 Software requirements

#### .NET Framework

The minimum requirements to operate the F-COM/STUDIO software are .NET Framework 3.5 platform installed and activated on the PC.

This component is typically present on PCs with Windows Seven (32 or 64 bit), Windows 8.0 (32 or 64 bit), Windows 8.1 (32 or 64 bit) and Windows 10 (32 or 64 bit) operating systems.

To find out whether Framework 3.5 is installed, simply install and run the F-COM/STUDIO software. If Framework 3.5 is not present, the operating system will generate an error message.

In order to install Framework 3.5, you must connect to the Microsoft website and download and install the file named `dotNetFx40_Full_x86_x64.exe`. For Windows 10 series operating systems, activation is necessary and is achieved by accessing the "Programs and features - Activating or deactivating Windows functions" section under ".NET Framework".

### 2.5.2 Installation procedure

1. Access the reserved area of the [www.inim.it](http://www.inim.it) website
2. Download the **setup.exe** installation file of the F-COM/STUDIO software.
3. Copy the setup.exe file to the desktop and start the execution as an "administrator" of the Windows system "(by right-clicking on the file icon).
4. Work through the installation wizard process.

#### Note

*In the initial installation phase, the guided procedure asks which users of the Windows system the installation is addressed to ("all users" or "current user").*

*Please note that if you select the current user, the material produced by the software (database, saved solutions) will be available exclusively for the current user and not for other users who have access to the computer or system in use.*

*If you select "all users" the material will be available to all users.*

5. On completion of the installation, the F-COM/STUDIO icon will appear on your desktop:



## 2.6 Events log

By clicking on the **Events log** button, the related section allows viewing of the communicator events log via a table, in which each row refers to a single event.

Each event shows the date and time of its occurrence and its description.



## 2.7 Real-time

Clicking on the **Real-time** button accesses a section which, after a direct connection with the communicator, makes it possible to perform real-time monitoring on the entire system and access the values of the following parameters:



- status of input/output terminals (activation, reset, interconnection fault)
- list of any telephone contacts for which supervision has failed
- list of any detected faults
- GSM status (network registration, 2G/3G technology, operator, signal, last credit reading)
- power supply and battery status
- any communications in progress and pending (telephone queue) on the cellular network and telephone line

## 3. Programming via software

### 3.1 Programming

Programming the communicator via the F-COM/STUDIO software is possible only when the installation of the system is complete and the relative configuration has been downloaded to the PC in use.

1. Create a new solution (via the **New**  button on the menu) or open a previously saved solution (via the **Open**  button on the menu).
2. Connect the apparatus to the PC in use.
3. Read the configuration, if necessary, by downloading it to the PC by means of the **Read** button.
4. First select the programming section using the buttons to the left (*Table 2.3: Home page [B]*) and then customize the programming parameters in the respective section that appears on the right.
5. To download the data to the communicator, click-on **Write** .

#### Note

*If an error occurs during the writing phase, it will be necessary to repeat the operation. Any data currently on the communicator will be overwritten.*

6. If necessary, save the solution (by means of the **Save**  button on the menu).  
The installer is allowed to program the communicator completely (Access levels).

### 3.2 Settings

This programming section allows you to set the general parameters of the F-COM communicator operating options.



**Table 3.5:** Parameter "Settings"

Parameter/Option	Function	Value/notes
<b>Communicator language</b>	The language selected for the communicator (user menu, installer menu, for predefined SMS texts and voice messages).	<ul style="list-style-type: none"> <li>• English (by default)</li> <li>• Italian</li> </ul>
<b>Installer PIN</b>	Box for the installer PIN (to change the programming options).	In order to simplify entry of this 6 digit PIN at the local keypad, it requires the use only of numbers included between "0" and "3".

Parameter/Option	Function	Value/notes
<b>Serial number</b>	This is the serial number of the communicator, available following a reading operation.	Uneditable
<b>Communication channels</b>	<p>Section to indicate the enabled communication channels.</p> <p>By clicking on the  icon relating to each channel, it is possible to set further parameters of the single communicator channel:</p>	<ul style="list-style-type: none"> <li>• Telephone line (enabled by default)</li> <li>• GSM Channel (enabled by default)</li> <li>• Mobile data network (disabled by default to prevent unwanted charges).</li> </ul>
<b>Telephone line-down fault delay</b>	<p>This parameter can be set by clicking on the  icon relating to the "Telephone line".</p> <p>This parameter allows you to program the delay with which the telephone line fault event will be generated with respect to the moment when it is actually detected.</p>	<p>From 0 to 65534 seconds; if set at 65535 the fault will not be signalled.</p> <p><b>EN-54</b> In order to ensure compliance with EN-54 standards, the default value (50 seconds) must not be changed.</p>
<b>Prefix</b>	Box for the telephone prefix to be placed before the telephone number for voice calls and Contact ID sent over the telephone line (PSTN).	Up to 8 digits
<b>GSM settings</b>	<ul style="list-style-type: none"> <li>• Volume input (microphone): adjustable from 0 to 99, preset at 40</li> <li>• Volume output (microphone): adjustable from 0 to 15, preset at 7</li> <li>• Balancing signal of the microphone that returns to the speaker to indicate to the user that the line is not down: three adjustment levels - low / medium (default) / high</li> <li>• SMS forwarding number: indicates the telephone contact received SMS texts is to be forwarded to. If not set, SMS forwarding will be disabled.</li> </ul>	
<b>Mobile data network settings</b>	<ul style="list-style-type: none"> <li>• APN (Access Point Name)</li> <li>• Username for APN authentication</li> <li>• Password for APN authentication</li> </ul>	
<b>Pay-as-you-go balance</b>	Clicking on the respective icon  accesses the remaining credit enquiry parameters ("Pay-as-you-go balance" on the next page).	
<b>Communication attempts</b>	This is the number of call attempts allowed before deleting the number from the call queue.	from 1 to 255
<b>Mains failure delay</b>	This parameter allows you to program the delay between detection of mains failure and the actual signalling of the event itself.	<p>from 50 to 65535 seconds</p> <p><b>EN-54</b> In order to ensure compliance with EN-54 standards this value must not exceed 60 seconds.</p>
<b>Number of repetitions</b>	Number of repetitions of voice messages.	from 1 to 255

Parameter/Option	Function	Value/notes
<b>Enable battery faults</b>	Option which, if enabled, will enable signalling of battery fault/battery restored events.	<b>EN-54</b> In order to ensure compliance with EN-54 standards this option must be enabled.
<b>Alarm restore follows the input</b>	Option which, if enabled, when the "ALARM CALL" input is restored, the "Alarm ACK" signalling LED, the "ALARM ACK" output and the alarm buzzer signal will also be restored.	
<b>Voice after dial</b>	Option which, if enabled, enables playback of voice messages after dialing the number.	
<b>Confirm with star key</b>	Option which, if enabled, enables the request to confirm receipt of the communication which must take occur by pressing the "*" of the telephone.	<b>EN-54</b> In order to ensure compliance with EN-54 standards, this option must be activated.
<b>Keys audio feedback</b>	Option which, if enabled, enables the activation of the communicator buzzer to signal the confirmation or rejection of a user operation.	
<b>Sound on event</b>	Option which, if enabled, enables the activation of the communicator buzzer in the event of an alarm or fault.	
<b>Set current date/time</b>	Button that sets the communicator date and time indicated in the box at the side.	
<b>Daylight saving</b>	Option which, if enabled, enables the standard time/daylight saving time switchover. The switchover mode is based on the selection made in the boxes "Year" and "Geographical area" which are visible in the table.	

### 3.2.1 Pay-as-you-go balance

Clicking on the icon relating to the remaining credit request opens a subsection with which you can access the various parameters that manage the request.

**Table 3.6:** "Remaining credit" Parameters

Parameter/Option	Function	Value
<b>Disabled Automatic Manual</b>	Operating mode of the remaining credit request. The choice made enables or not the following options and parameters.	The "automatic" mode functions only for TIM and Wind operators. The "manual" mode must be customized by the installer in accordance with the credit request modes offered by the operator.
<b>Threshold</b>	Threshold value, in currency, for the activation/restoration of the insufficient credit event.	
<b>Period</b>	Time interval, in hours, between two subsequent credit requests.	

Parameter/Option	Function	Value
<b>Call SMS Feature code - USSD</b>	In case of "manual" request mode, this selection indicates how the credit request will be sent by the communicator.	<ul style="list-style-type: none"> <li>• Telephone call</li> <li>• SMS text message</li> <li>• Network command (USSD)</li> </ul>
<b>Requested number</b>	Telephone number to which the credit request is to be forwarded	
<b>Message request</b>	Text of the credit request message (only if the type of request is SMS text).	
<b>Answer number</b>	Telephone number the answer is expected from. If left empty the communicator will not perform any check on the number from which the answer comes from.	
<b>Answer pattern</b>	String to search for in the answer message. The numeric value that follows this string in the reply message is interpreted as a remaining credit.	

## 3.3 Input/Output terminals

The "Inputs/Outputs" programming section lists all the input and output terminals available on the F-COM communicator motherboard:



**Table 3.7: Programmable terminals**

Terminal	Number on PCB	Function
<b>ALARM CALL</b>	14, 15	Input terminal for the activation of alarm communications
<b>FAULT CALL</b>	16, 17	Input terminal for the activation of fault communications
<b>ALARM ACK</b>	6	Output terminal for confirmation of receipt of an alarm communication
<b>OUT1</b>	7	Programmable output terminal (by default it activates in the event of a connection fault)
<b>FAULT</b>	8	Output terminal that activates in the presence of communicator faults
<b>IO1</b>	10	Input/Output terminals
<b>IO2</b>	11	Input/Output terminals
<b>IO3</b>	12	Input/Output terminals

The software provides the parameters and options to be set for each terminal, in accordance with the function of the terminal.

**Table 3.8: "Input/Output" parameters**

Parameter/Option	Function	Value/notes	Terminals
<b>Direction</b>	Box to select the terminal direction	<ul style="list-style-type: none"> <li>Input</li> <li>Output</li> </ul>	IO1, IO2, IO3
<b>Polarity</b>	Box to select the terminal polarity	<ul style="list-style-type: none"> <li>Normally open (applied)</li> <li>Normally closed (removed)</li> </ul>	ALARM CALL, FAULT CALL, ALARM ACK, OUT1, FAULT, IO1, IO2, IO3
<b>Reference</b>	Box to select the terminal reference	<ul style="list-style-type: none"> <li>Negative (pull-up resistor integrated in the communicator enabled).</li> <li>Positive (pull-up resistor integrated in the communicator disabled).</li> </ul> <p>For the ALARM CALL and FAULT CALL inputs the reference is always negative without the possibility of programming.</p>	ALARM CALL, FAULT CALL, IO1, IO2, IO3
<b>Supervision</b>	Option that enables/disables supervision on the terminal. User programmable for all terminals.	<p><b>EN-54</b> In order to guarantee compliance with the EN-54 standards, this option must be activated for the ALARM CALL and FAULT CALL terminals.</p>	ALARM CALL, FAULT CALL, ALARM ACK, OUT1, FAULT, IO1, IO2, IO3
<b>Bistable/Monostable</b>	Option that establishes the operating mode of the output.	<ul style="list-style-type: none"> <li>Bistable (activates when the event activates and deactivates when the event restores)</li> <li>Monostable (activates when the event activates; in this case a box for the output activation time (in seconds) is enabled.</li> </ul>	OUT1, IO1, IO2, IO3

Parameter/Option	Function	Value/notes	Terminals
<p><b>Thresholds</b></p> 	<p>Button to open a window for adjustments to the input activation thresholds, in Volts or Ohms. The thresholds can be modified via the number boxes or by using the bar which indicates the levels by means of colours:</p> <p>In this window it is also possible to indicate the polarity and supervision of the input via the respective boxes.</p> <p>By pressing the <b>Real-time reading</b> a connection is made to the communicator which provides the reading of the voltage or resistance measured between the selected terminal and ground.</p> <p>The <b>OK</b> button saves the changes which will be written during the write phase.</p>	<ul style="list-style-type: none"> <li>• Volt (voltage between terminal and ground)</li> <li>• Ohm (resistance between terminal and ground)</li> <li>• yellow - connection fault (open or short circuit)</li> <li>• green - standby</li> <li>• red - alarm</li> </ul>	ALARM CALL, FAULT CALL, IO1, IO2, IO3
<p><b>Functions</b></p>	<p>Boxes to select the functions associated with the inputs.</p>  <p>The icon indicates that at least one feature is associated.</p> <p>The programming of a function for a specific terminal inhibits the implementation of the actions programmed in the section "Events/Actions" on page 23 for the activation/restore event of the terminal.</p>	<ul style="list-style-type: none"> <li>• Cancel alarm communications</li> <li>• Cancel fault communications</li> <li>• Cancel other communications</li> <li>• Disable alarm communications</li> <li>• Disable fault communications</li> <li>• Disable other communications</li> <li>• Force telephone line</li> <li>• Force cellular channel</li> <li>• Rearm</li> </ul>	IO1, IO2, IO3

## 3.4 Phonebook (Contacts)

The "Phonebook" programming section shows a list of 32 contacts.

The software provides the parameters and options to be set, in accordance with the associated communication type.

At the top of the section are buttons to filter viewing of contacts in accordance with their programming.



**Table 3.9: "Phonebook" parameters**

Parameter/Option	function	value/notes	communication protocol
<b>Label</b>	Box to edit the label that identifies the contact		all
<b>Type</b>	Box to select the protocol to use for communications with the contact.	<ul style="list-style-type: none"> <li>• Not defined</li> <li>• Item</li> <li>• Contact-ID</li> <li>• SIA-IP</li> <li>• SMS</li> <li>• IP2RX</li> </ul>	all
<b>Number</b>	Box for the telephone number	maximum 20 digits	<ul style="list-style-type: none"> <li>• Item</li> <li>• Contact-ID</li> <li>• SMS</li> </ul>
<b>IP address</b>	Box for the IP address of the digital receiver		<ul style="list-style-type: none"> <li>• SIA-IP</li> <li>• IP2RX</li> </ul>
<b>Port</b>	Field for the port of the digital receiver		<ul style="list-style-type: none"> <li>• SIA-IP</li> <li>• IP2RX</li> </ul>
<b>Supervision</b>	<p>Option that enables/disables the supervision of contacts, which is achieved through a periodic communication which, if unsuccessful, will be repeated a number of times as set by the "Communication attempts" parameter.</p> <p>If activated, the time interval can be entered in the box below, expressed in days, hours and minutes (DD hh:mm), between two successive supervision operations.</p> <p> The button accesses the supervision parameters.</p>	<p><b>EN-54</b></p> <p>In order to ensure compliance with EN-54 standards this option must be activated and the time interval must not be less than 24 hours.</p>	<ul style="list-style-type: none"> <li>• Item</li> <li>• Contact-ID</li> <li>• SIA-IP</li> <li>• IP2RX</li> </ul>
<b>Start time</b> <b>End time</b>	Boxes for the start and end times of supervision calls (hh:mm).	<p>By default, the start time is 09:00 and the end time is 17:00.</p> <p>If these settings are done through the screen, they are disabled by default (00:00).</p>	<ul style="list-style-type: none"> <li>• Item</li> </ul>
<b>Voice message</b>	Box for the selection of the supervision supervision-operation voice message.	If not programmed, the periodic message in Italian (index "3") or in English (index "6") is used based on the language selected.	<ul style="list-style-type: none"> <li>• Item</li> </ul>
<b>Event code</b>	Boxes for the event code of the supervision call.	If not programmed, the default event code will be used: "602";.	<ul style="list-style-type: none"> <li>• Contact-ID</li> </ul>

Parameter/Option	function	value/notes	communication protocol
<b>Preferred channel</b>	Box to select the preferred communication channel.	<ul style="list-style-type: none"> <li>Telephone line</li> <li>Cellular channel</li> </ul>	<ul style="list-style-type: none"> <li>Item</li> <li>Contact-ID</li> </ul>
<b>Backup SMS</b>	Option that enables/disables the sending of an SMS text when all the attempts of a voice call have failed.		<ul style="list-style-type: none"> <li>Item</li> </ul>
<b>Account code</b>	Box for the account code to be used for digital communications		<ul style="list-style-type: none"> <li>Contact-ID</li> <li>SIA-IP</li> <li>IP2RX</li> </ul>
<b>Encryption</b>	Box for selection of the encryption algorithm. Once selected, it is possible to insert the encryption key in the box next to it.	<ul style="list-style-type: none"> <li>None</li> <li>AES 128 bit</li> <li>AES 192 bit</li> <li>AES 256 bit</li> </ul>	<ul style="list-style-type: none"> <li>SIA-IP</li> <li>IP2RX</li> </ul>
<b>Event label</b>	Option that enables/disables the addition of the event description in the data packet sent to the digital receiver.		<ul style="list-style-type: none"> <li>SIA-IP</li> <li>IP2RX</li> </ul>

## 3.5 Events

The events managed by the communicator are listed in the table below.

The "Events log" column indicates whether the event activation and event restored data is recorded in the events log.

The "Activate Actions" column indicates whether the communicator can be programmed to trigger an action when the event occurs ("Events/Actions" on page 23).

The "Restores..." column is empty for non-resettable events.

**Table 3.10:** Event type

Event	Type	Activates...	Restores...	Events log	Activate actions
<b>ALARM CALL Input</b>	Alarm	on activation of the ALARM CALL input	on restore of the ALARM CALL input	<b>Yes</b>	<b>Yes</b>
<b>FAULT CALL Input</b>	Fault	on activation of the FAULT CALL input	on restore of the FAULT CALL input	<b>Yes</b>	<b>Yes</b>
<b>IO1 Input</b>	Generic	on activation of input IO1	on restore of input IO1	<b>Yes</b>	<b>Yes</b>
<b>IO2 Input</b>	Generic	on activation of input IO2	on restore of input IO2	<b>Yes</b>	<b>Yes</b>
<b>IO3 Input</b>	Generic	on activation of input IO3	on restore of input IO3	<b>Yes</b>	<b>Yes</b>
<b>Output</b>	Generic	on activation of an output terminal	on restore of an output terminal	<b>Yes</b>	<b>No</b>
<b>Interconnection fault</b>	Fault	when a supervised terminal is shorted or open	when no terminal is in fault status	<b>Yes</b>	<b>Yes</b>

Event	Type	Activates...	Restores...	Events log	Activate actions
<b>Battery trouble</b>	Fault	when the battery is inefficient, discharged or short-circuited	when the battery has no problems	<b>Yes</b>	<b>Yes</b>
<b>Missing battery</b>	Fault	when the battery is disconnected	when the battery is connected	<b>Yes</b>	<b>Yes</b>
<b>Power supply trouble</b>	Fault	when the power supply is absent, overloaded or overheated	when the power supply is free of problems	<b>Yes</b>	<b>Yes</b>
<b>Mains fault</b>	Fault	when the mains supply fails	when the mains supply restores	<b>Yes</b>	<b>Yes</b>
<b>Ground fault</b>	Fault	when leakage to ground is detected	when leakage to ground is no longer detected	<b>Yes</b>	<b>Yes</b>
<b>Data corruption</b>	Fault	when the programming data is corrupted	when the programming data is valid	<b>Yes</b>	<b>Yes</b>
<b>System restart</b>	Fault	when the communicator is restarted		<b>Yes</b>	<b>Yes</b>
<b>Rearm</b>	Generic	when the communicator rearms		<b>Yes</b>	<b>Yes</b>
<b>Factory default</b>	Generic	when programming restores to factory default data		<b>Yes</b>	<b>No</b>
<b>Programming</b>	Generic	at the start of a programming session	on exiting a programming session	<b>Yes</b>	<b>No</b>
<b>Changed date/time</b>	Generic	when the communicator date/time is refreshed		<b>Yes</b>	<b>Yes</b>
<b>PIN entered</b>	Generic	when a user/installer PIN is recognized		<b>Yes</b>	<b>Yes</b>
<b>Wrong PIN</b>	Generic	when a wrong PIN is entered		<b>Yes</b>	<b>Yes</b>
<b>Telephone line trouble</b>	Fault	when the presence of the telephone line is no longer detected	when the presence of the telephone line is detected	<b>Yes</b>	<b>Yes</b>
<b>SIM Error</b>	Fault	when the presence of a GMS SIM is not detected	when the presence of a GMS SIM is detected	<b>Yes</b>	<b>Yes</b>
<b>Insufficient SIM Credit</b>	Fault	when the remaining credit is less than the programmed threshold	when the remaining credit is more than the programmed threshold	<b>Yes</b>	<b>Yes</b>
<b>GSM trouble</b>	Fault	when the communicator fails to connect to the GSM network or the signal is weak	when the communicator connects properly to the GSM network	<b>Yes</b>	<b>Yes</b>

Event	Type	Activates...	Restores...	Events log	Activate actions
<b>Mobile data network trouble</b>	Fault	when the SIM is not enabled for data traffic or the communicator cannot connect to the data network	when the communicator connects to the data network	<b>Yes</b>	<b>Yes</b>
<b>Communications cancelled</b>	Generic	when communications in progress are cancelled		<b>Yes</b>	<b>No</b>
<b>Communications enabled/disabled</b>	Generic	when communications are disabled	when communications are enabled	<b>Yes</b>	<b>No</b>
<b>Communication started</b>	Generic	at the start of a communication		<b>Yes</b>	<b>No</b>
<b>Communication confirmed</b>	Generic	on confirmation of receipt of a communication		<b>Yes</b>	<b>No</b>
<b>Failed communication</b>	Generic	when a communication is not confirmed (if the communicator is programmed to request confirmation)		<b>Yes</b>	<b>No</b>
<b>Contact supervision trouble</b>	Fault	when the periodic test communication is not confirmed by a supervised telephone contact	when all supervised telephone contacts confirm receipt of a communication	<b>Yes</b>	<b>No</b>
<b>Code 0 diagnostic information</b>	Diagnostics	when the presence of diagnostic information is detected		<b>Yes</b>	<b>No</b>
<b>Code 1 diagnostic information</b>	Diagnostics	when the presence of diagnostic information is detected	when the presence of diagnostic information is detected	<b>Yes</b>	<b>No</b>

## 3.6 Events/Actions

The "Events/Actions" programming section shows a table in which each line indicates, for a selected event, which actions will be performed by the communicator (voice / digital / SMS communications and activation of programmable outputs).



The number of lines (maximum number of events that can be associated with actions) is 32.

The same event can be specified in more than one line of the matrix. When an event occurs, the communicator will perform all the actions specified in the lines that correspond to the event.

There are buttons at the top of the section to filter the contacts in accordance with their programming.



**Table 3.11: "Event / Actions" parameters**

Parameter/Option	function	value/notes
<b>Event</b>	<p>Box for the selection of the type of event that will trigger the specified actions.</p> <p>The selectable events are a part of the events managed by the communicator, as indicated in the table "Event type" on page 21, in the "Action activation" column.</p>	<ul style="list-style-type: none"> <li>• ALARM CALL Input</li> <li>• FAULT CALL Input</li> <li>• IO1 Input</li> <li>• IO2 Input</li> <li>• IO3 Input</li> <li>• Interconnection fault</li> <li>• Battery trouble</li> <li>• Missing battery</li> <li>• Power supply trouble</li> <li>• Mains fault</li> <li>• Ground fault</li> <li>• Data corruption</li> <li>• System restart</li> <li>• Rearm</li> <li>• Changed date/time</li> <li>• User-code entry</li> <li>• Wrong user code</li> <li>• Telephone line down</li> <li>• SIM Error</li> <li>• Insufficient SIM Credit</li> <li>• GSM fault</li> <li>• Mobile data network trouble</li> </ul>
<b>Type</b>	<p>Box for the selection of the type of occurrence of the event.</p> <p>Indicates whether the specified actions must be performed only when the event is activated, or only when the event is restored or in both cases.</p>	<ul style="list-style-type: none"> <li>• Not defined</li> <li>• Activation</li> <li>• Reset</li> <li>• Both</li> </ul>
<b>Output</b>	<p>Box where you can indicate a programmable output to be activated in response to the indicated event.</p>	<ul style="list-style-type: none"> <li>• Not defined</li> <li>• OUT1</li> <li>• IO1</li> <li>• IO2</li> <li>• IO3</li> </ul>
<b>Contacts</b>	<p>Box where you can select the contacts who will receive forwarded communications.</p> <p> The icon  indicates that at least one contact is selected.</p>	
<b>SMS text</b>	<p>Box where you can select the index or label of the SMS message (present in the SMS "SMS text message library" on page 29) which will be sent to the selected contacts in response to the indicated event.</p> <p>Field valid only for "SMS" contacts.</p>	<p>If no SMS message is selected, the communicator will send predefined messages ("Events/Actions default programming" on page 27).</p>
<b>Advanced</b>	<p> The  button gives access to advanced parameters specific to the selected event.</p>	

Parameter/Option	function	value/notes
<b>C.ID Event</b>	Boxes for the event code to be used in digital communications to Contact ID contacts.	If this field is not programmed, the communicator will use the default event code ("Events/Actions default programming" on page 27).
<b>SIA Event activation</b>	Box for the event code to be used in digital communications to SIA-IP or IP2RX contacts in the case of event activation.	If this field is not programmed, the communicator will use the default event code ("Events/Actions default programming" on page 27).
<b>SIA Event reset</b>	Box for the event code to be used in digital communications to SIA-IP or IP2RX contacts in the case of event reset.	If this field is not programmed, the communicator will use the default event code ("Events/Actions default programming" on page 27).
<b>Where</b>	Box for the selection of the identification code of the partition/zone to be specified in digital communications to Contact ID, SIA-IP or IP2RX contacts. This information is to be entered in the "GG" field for Contact ID and in the Partition field for SIA-IP.	If this option is not programmed, the communicator will use the predefined value ("Events/Actions default programming" on page 27).
<b>Who</b>	Box for the selection of the identification code of the point/user to be specified in digital communications to Contact ID, SIA-IP or IP2RX contacts. This information is to be entered in the "CCC" field for Contact ID and in the "Address" field for SIA-IP.	If this option is not programmed, the communicator will use the predefined value ("Events/Actions default programming" on page 27).
<b>Voice messages</b>	Boxes for the selection of the index of the voice message (present in the "Voice message library" on page 29) to be present in the communication to the contacts selected for the indicated event. Field valid only for "Voice" contacts.	It is possible to select a maximum of 4 messages. The selected messages are played in sequence.

### Activation actions of a bistable output

- Activated and deactivated respectively on activation and reset of the associated event regardless of the "type" parameter indicated in the events/actions table.
- If the same output is associated with several events, it will be deactivated only when all the events reset ("OR" logic).
- If an output is associated with a non-resettable event (system restart, rearm, date/time change, user code entry, wrong user code), it will reset only on rearming (activation of an IO1 input, ..., 3 which has the "rearm" function enabled or through the user menu via the screen).
- A bistable output must not be associated with the "rearm" event as it will be unable to reset.

#### Note

*The installer must pay particular attention to the programming of the bistable outputs. If the bistable output is associated with a non-resettable event (system restart, rearm, date/time change, user code entry, wrong user code) or if "activation" or "reset" is indicated as the "Type", the output will reset when the communicator rearms.*

## Activation actions of a monostable output

- Activation occurs coherently with the setting in the "Type" field in the events/actions table for the programmed duration.
- The output can be reactivated: if the output is active (the programmed duration has not yet expired) and the activation conditions occur again (a new event associated with the output occurs or a new activation of the same event ), the expiry of the deactivation timer is refreshed.
- The output will be deactivated immediately when the communicator rearms (activation of an IO1 input, ..., 3 which has the "rearm" function enabled) or from the user menu via the screen).

## Communication activation actions

The beginning of a programming session and the detection of a fault in the corruption of programming options, block current communications and cancel those waiting.

### 3.6.1 Events enabled by default

The following table shows which of the available events are enabled by default and which actions are consequent to their occurrence:

**Table 3.12:** Events/Actions enabled by default

Event	Output	Contacts	Voice calls	SMS text message	Contact ID event	SIA-IP/IP2RX event
<b>ALARM CALL Input</b>	activation	None	Contacts #1 and #2	"Fire alarm"	"Fire alarm"	110 FA
<b>FAULT CALL Input</b>	activation	None	Contacts #1 and #2	"Fire system trouble"	"Fire system fault"	300 FT
<b>Interconnection fault</b>	activation	None	Contacts #1 and #2	"Fire system trouble"	"Interconnection fault"	380 FT
<b>Interconnection fault</b>	activation / restore	OUT1	None	None	Empty	None None
<b>Battery trouble</b>	activation / restore	None	Contacts #1 and #2	None	"Battery trouble"/"Restore battery trouble"	309 YT / YR
<b>Missing battery</b>	activation / restore	None	Contacts #1 and #2	None	"Missing battery"/"Restore missing battery"	311 YM / YR
<b>Power supply trouble</b>	activation / restore	None	Contacts #1 and #2	None	"Power supply trouble" / "Restore power supply trouble"	300 YP / YQ
<b>Mains fault</b>	activation / restore	None	Contacts #1 and #2	None	"Mains fault" / "Restore mains fault"	301 AT / AR
<b>Ground fault</b>	activation / restore	None	Contacts #1 and #2	None	"Ground fault" / "Restore ground fault"	310 UT / UR

Event		Output	Contacts	Voice calls	SMS text message	Contact ID event	SIA-IP/IP2RX event
<b>Telephone line trouble</b>	activation / restore	None	Contacts #1 and #2	None	"Telephone line trouble" / "Restore telephone line trouble"	350	LT / LR
<b>SIM Error</b>	activation / restore	None	Contacts #1 and #2	None	"SIM error" / "Restore SIM error"	350	YS / YK
<b>Insufficient SIM Credit</b>	activation / restore	None	Contacts #1 and #2	None	"SIM credit low" / "Restore SIM credit low"	350	YS / YK
<b>GSM trouble</b>	activation / restore	None	Contacts #1 and #2	None	"GSM trouble" / "Restore GSM trouble"	350	YS / YK
<b>Mobile data network trouble</b>	activation / restore	None	Contacts #1 and #2	None	"Mobile data network trouble" / "Restore mobile data trouble"	350	YS / YK

With these default settings and by following the steps of the guided programming that starts at the first power up, basic programming is achieved.

For example, by setting contact #1 as a "voice" phone number and contact #2 with an "SMS" or "Contact ID" phone number, you will achieve:

- a voice call for the "ALARM CALL" input activation event
- a voice call for the "FAULT CALL" input activation event
- an SMS (with default text) or a digital communication (with a default event code) for the most common faults.

### 3.6.2 Events/Actions default parameters

**Table 3.13:** Events/Actions default programming

Event		SMS text message	Contact ID event	SIA-IP/IP2RX event	Where	Who
<b>ALARM CALL Input</b>	activation	"Fire alarm"	110	FA	0	0
	reset	"Reset fire alarm"		FH		
<b>FAULT CALL Input</b>	activation	"Fire system fault"	300	FT	0	0
	reset	"Reset fire system fault"		FJ		
<b>I01 Input</b>	activation	"Activation input I01"	750	UX	0	0
	reset	"Reset input I01"				
<b>I02 Input</b>	activation	"Activation input I02"	750	UX	0	0
	reset	"Reset input I02"				
<b>I03 Input</b>	activation	"Activation input I03"	750	UX	0	0
	reset	"Reset input I03"				

Event		SMS text message	Contact ID event	SIA-IP/IP2RX event	Where	Who
<b>Interconnection fault</b>	activation	"Interconnection fault"	380	FT	0	<ul style="list-style-type: none"> <li>• 0 ALARM CALL</li> <li>• 1 FAULT CALL</li> <li>• 2 ALARM AC</li> <li>• 3 OUT1</li> <li>• 4 FAULT</li> <li>• 5 IO1</li> <li>• 6 IO2</li> <li>• 7 IO3</li> </ul>
	reset	"Restore interconnection fault"		FJ		
<b>Battery trouble</b>	activation	"Battery fault"	309	YT	0	0
	reset	"Restore battery trouble"		YR		
<b>Battery missing</b>	activation	"Missing battery"	311	YM	0	0
	reset	"Restore missing battery"		YR		
<b>Power supply trouble</b>	activation	"Power supply trouble"	300	YP	0	0
	reset	"Restore power supply trouble"		YQ		
<b>Mains fault</b>	activation	"Mains fault"	301	AT	0	0
	reset	"Restore mains fault"		AR		
<b>Ground fault</b>	activation	"Ground fault"	310	UT	0	0
	reset	"Reset Ground fault"		UR		
<b>System restart</b>	/	"System restart"	305	RR	0	0
<b>Rearm</b>	/	"Rearm"	406	RR	0	0
<b>Changed date/time</b>	/	"Changed date/time"	000	JT	0	0
<b>PIN entered</b>	/	"User-code entry"	462	UX	0	<ul style="list-style-type: none"> <li>• 0 Standard user</li> <li>• 1 Advanced user</li> <li>• 2 Installer</li> </ul>
<b>Wrong PIN</b>	/	"Wrong user code"	461	UX	0	0
<b>Telephone line down</b>	activation	"Telephone line down"	350	LT	0	0
	reset	"Restore telephone line down"		LR		
<b>SIM Error</b>	activation	"SIM Error"	350	YS	0	0
	reset	"Restore SIM error"		YK		
<b>Insufficient SIM Credit</b>	activation	"Insufficient SIM Credit"	350	YS	0	0
	reset	"Reset insufficient SIM Credit"		YK		

Event		SMS text message	Contact ID event	SIA-IP/IP2RX event	Where	Who
GSM fault	activation	"GSM trouble"	350	YS	0	0
	reset	"Restore GSM trouble"		YK		
Mobile data network trouble	activation	"Mobile data network trouble"	350	YS	0	0
	reset	"Reset mobile data network trouble"		YK		

## 3.7 SMS text message library

The "SMS" programming section provides the list of available SMS messages.

The communicator is capable of managing 32 SMS messages of 140 characters each.



There are buttons at the top of the section to filter the contacts in accordance with their programming.



**Table 3.14:** "SMS" parameters

Parameter/Option	function	value/notes
<b>Label</b>	Box for the SMS text message label. The software uses this label for the selection of text messages in the matrix "Events/Actions" on page 23 for "SMS" contact communications.	
<b>SMS text</b>	Box where it is possible to edit the message text.	Maximum 140 digits
	Button to delete the SMS message in the corresponding line.	

## 3.8 Voice message library

The "Voice message" programming section provides the list of the available voice messages.

The communicator is capable of managing 100 voice messages. 94 user programmable plus 6 preset for a total duration of 500 seconds.



The first 6 messages on the list are default messages and are used by default for alarm and fault activations and for the monitoring of contacts:

- Message #1: "Allarme incendio"; (Italiano)
- Message #2: "Fire system trouble";
- Message #3: "Messaggio periodico"; (Italiano)
- Message #4: "Fire alarm"; (English)

- Message #5: "Fire system trouble"; (English)
- Message #6: "Periodic message"; (English)

The 6 predefined messages cannot be changed by the installer.

The software provides parameters to be set for each message.



The  icon indicates that the message has undergone programming changes.

If the installer resets the factory data, only the 94 programmable messages will be deleted while the 6 predefined messages will remain unchanged.

**Table 3.15:** "Voice message" parameters

Parameter/Option	function
<b>Label</b>	Box for the voice message label. The software uses this label for the selection of the voice messages in the matrix "Events/Actions" on page 23 for "Voice" type contact communications.
	Button that allows the selection of an audio file in the PC to be used as a voice message. F-COM/STUDIO supports "wave" (.wav) format.
	Button to open the window for the "text to speech" function that converts text messages, edited in the appropriate box, into voice messages.
	Button that starts playback of the selected voice message.
	Button to delete the voice message in the corresponding line.

Inside this section of the software, the **Read** and **Write** buttons on the menu bar at the top allow you to download and load the programming for the voice messages only.







---

Via dei Lavoratori 10, Centobuchi  
63076 Monteprandone (AP) ITALY  
Tel. +39 0735 705007 \_ Fax +39 0735 704912

info@inim.it \_ [www.inim.it](http://www.inim.it)



DCMPINE0FCOM-110-20250110